

***ALWAYS CHECK THE OIL LEVEL WITH
THE LIFTING ARM IN THE LOWEST POSITION***

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
<u>Jacks, Manual</u>					
2T-C	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-77	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
3T-C	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
4T-C (G4)	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T-C (G3)	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
6T-C (G3)	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
10T-C (G3)	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
12T-C	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
15T-C (G1)	2,60	CASTROL - AWS 22		10 mm under the refilling hole	
20T-C (G1)	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
1.4T-HC 77	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-HC (G3)	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
3T-HC (G3)	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T-HC (G1)	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
6T-HC (G1)	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
8T-HC (G2)	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
10T-HC (G4)	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
<u>Jacks, Air hydraulic</u>					
A28-HC (G1)	2,60	CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
A3216-C (G1)	1,20	CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
A4020-C (G1)	1,20	CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
A4422-C (G1)		CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
A5816-C (G1)	1,80	CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
A5830-C (G1)	3,40	CASTROL - ATF DEX II		Up to the edge of the refilling hole	8 -12 bar
<u>Presses, Foot operated</u>					
FP 16 (G2)	1,40	CASTROL - AWS 22	CASTROL - AWS 32		
FP 20 (G6)	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
FP 25 (G6)	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
FP 30 (G6)	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
FP 40 (G1)	4,00	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
FP 50 (G2)	4,00	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
<u>Presses, Hand operated</u>					
HP 20 (G6)	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP 25 (G6)	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP 30 (G6)	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP 40 (G1)	4,00	CASTROL - AWS 22	CASTROL - AWS 32	110 mm under the refilling hole	
HP 50 (G2)	4,00	CASTROL - AWS 22	CASTROL - AWS 32	110 mm under the refilling hole	
HP 60 (G1)	5,00	CASTROL - AWS 22	CASTROL - AWS 32	80 mm under the refilling hole	
HP 70 (G1)	6,00	CASTROL - AWS 22	CASTROL - AWS 32	80 mm under the refilling hole	
HP 100 (G4)	??	CASTROL - AWS 22	CASTROL - AWS 32	50 mm under the refilling hole	
<u>Presses, Electro-hydraulic</u>					
EP 40	15,00	CASTROL - AWS 32			
EP 40 D	15,00	CASTROL - AWS 32			
EP 60	18,00	CASTROL - AWS 32			
EP 60 D	18,00	CASTROL - AWS 32			

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
EP 100 D G6	19,00	CASTROL - AWS 32			
<u>Spring compressors</u>					
CSC	0,00	No oil in machine	No oil in machine	No oil in machine	8 - 10 bar
CSC+	0,00	No oil in machine	No oil in machine	No oil in machine	8 - 10 bar
<u>Bottle jacks</u>					
CBJ 3	0,09	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 5	0,15	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 10	0,24	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 15	0,34	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 20	0,47	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 25	0,49	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 30	0,55	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 50	0,85	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ-T4	0,15	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ-T10	0,65	CASTROL - AWS 22		Up to the edge of the refilling hole	
<u>Cranes</u>					
CC 055	0,85	CASTROL - AWS 22		Up to the edge of the refilling hole	
CC 10	0,85	CASTROL - AWS 32		Up to the edge of the refilling hole	
CC 15P	2,80	CASTROL - AWS 32		Up to the edge of the refilling hole	
<u>Transmission jacks</u>					
TJ 300	0,95	CASTROL - AWS 32			
TJ 325	0,95	CASTROL - AWS 32		Up to the edge of the refilling hole	
TJ 525	0,95	CASTROL - AWS 32		Up to the edge of the refilling hole	
TJ 1000	0,95	CASTROL - AWS 32		Up to the edge of the refilling hole	

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
TJ-T 1300	2,80	CASTROL - AWS 32		Up to the edge of the refilling hole	
TJ-T 2000	5,50	CASTROL - AWS 15		Up to the edge of the refilling hole	
<u>Wheel dollies</u>					
WD Mobile	0,00	No oil in machine	No oil in machine	No oil in machine	
WD 60	0,95	CASTROL - AWS 22		10 mm under the refilling hole	
WD 500	0,95	CASTROL - AWS 22			
WD 800	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
WD 1500	0,80	CASTROL - AWS 22		10 mm under the refilling hole	
WD 1600	0,80	CASTROL - AWS 22		10 mm under the refilling hole	
<u>Hydraulic body repair kits</u>					
CRK 4	0,50	CASTROL - AWS 22		Under the refilling hole	
CRK 10	0,50	CASTROL - AWS 22		Under the refilling hole	
<u>Jacks, Manuel</u>					
1T-2H	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,3T-H	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1.5T-HC (G3)	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-1HL; 1,5T-2HL	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-2	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-2S	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-C	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-H	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-HA	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5TH-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-H-US	0,50	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
1,5T-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-1B	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-1V	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2HA	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2HA-B	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2L	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2LS	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2Q	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4A	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4B	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4K	0,50	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
2T-4KS	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4Q	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4Q-TE	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-5H	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
2T-Au	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-F (G1/G3)	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-LF	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2T-LF2	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2TK-5	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2TQ-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2TQ-LJ-TE	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-V; 2T-V-Boogie	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,25T-2L	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,25T-4K	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-1	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-4K	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-4Q	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-5H	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
3T-1B	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
3T-5H	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
3T-V	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
4,5T-4	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
4T-4	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T-2QA	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T-3Q-US-2	0,90	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
6T-2H	1,40	CASTROL - AWS 22		10 mm under the refilling hole	
6T-4	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
6T-K	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
6T-HC	1,40	CASTROL - AWS 22		10 mm under the refilling hole	
7,5T-2H	1,40	CASTROL - AWS 22		10 mm under the refilling hole	
7.5T-4	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
8T-1	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
8T-C (G3)	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
10T-2A	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-4	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-4M	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-4-US-3	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-K	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
10T-C (G1/G2)	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
12T-2	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
15T-2	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
15T-2M	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
20T-1M	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
<u>Jacks, Other models</u>					
ALU-C (G1/G2)	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
CFLJ-4	0,80	CASTROL - AWS 22		10 mm under the refilling hole	
CFLJ-5	0,80	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
<u>Jacks, Air hydraulic</u>					
A2-2; A3-2	0,50	CASTROL - AWS 22		65 mm under the refilling hole	8 - 10 bar
A2510-3; A2510-4	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A2510-C (G1/G4)	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
A2510-C (G5)	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
A4020-1	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A4411-C (G1/G4)	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
A4411-C (G5)	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
A4422-C (G1/G4)	3,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
A4422-C (G5)	3,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -12 bar
AM5 1,5T-F	0,55	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 2,5T-5H	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 3T-C	0,55	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 3T-5H	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 4T-4	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 5T-3QA	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 5T-3Q-US-2	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 10T-2-US	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 10T-4	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 15T-2	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 18T-1	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5-18T-2L	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 20T-1-US	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AV20-2; A4020-2	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
AV20-C (G1/G4)	3,00	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
AV20-C (G5)	3,00	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
AV22-2; AV20-3	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
Presses, Foot operated					

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
FP16 (G1)		CASTROL - AWS 22			
FP20-AA/AR	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	6 - 8 bar
FP20 (G2/G4/G5)	2,25	CASTROL - AWS 22			
FP25 (G2/G4/G5)	2,25	CASTROL - AWS 22			
FP50 (G1)	4,00	CASTROL - AWS 22			
<u>Presses, Hand operated</u>					
HP15	1,50	CASTROL - AWS 22	CASTROL - AWS 32		
HP20-AR	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP20-AA/AR	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	6 - 8 bar
HP20 (G2/G5)	2,25	CASTROL - AWS 22			
HP25	3,00	CASTROL - AWS 22	CASTROL - AWS 32		
HP25-1 (with 15T pump)	1,50	CASTROL - AWS 22	CASTROL - AWS 32		
HP25 Junior	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP25 (G2/G5)	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP50 (G1)	4,00	CASTROL - AWS 22			
HP100 (G1)	10,00	CASTROL - AWS 22	CASTROL - AWS 32	40 mm under the refilling hole	
HP125	10,00	CASTROL - AWS 22	CASTROL - AWS 32		
HP100 (G3)	6,00	CASTROL - AWS 22	CASTROL - AWS 32	50 mm under the refilling hole	
HP100F (G2)					
<u>Cranes</u>					
CC 05, CC 05P, CC 05-J	0,80	CASTROL - AWS 32		Up to the edge of the refilling hole	
CC 10L (G2/G3)	0,80	CASTROL - AWS 32		Up to the edge of the refilling hole	
K1					
K05					
K05-2					
K15					

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
<u>Presses, Electro-hydraulic</u>					
EP25-1/ EP25-1D/ EP25-1D-3/ EP25	14,00	CASTROL - AWS 32			
EP100-2/ EP100-2D-3/ EP100-2D-4 EP100-2D-320	27,00	CASTROL - AWS 32			
EP125-2/ EP125-2D-3/ EP125-2D-4	27,00	CASTROL - AWS 32			
EP(MP)150-2D-4	30,00	CASTROL - AWS 32			
EP40-1/ EP40-1D/ EP40-1D-3/ EP40	14,00	CASTROL - AWS 32			
EP60-1	14,00	CASTROL - AWS 32			
EP60-2/ EP60-2D-3/ EP60-2D-4	27,00	CASTROL - AWS 32			
MP 1 trins	14,00	CASTROL - AWS 22			
MP 2 trins	30,00	CASTROL - AWS 22			
MDP10-1	14,00	CASTROL - AWS 32			
MPC10-1/ MPC10-1-H/ MPC10-1D/	11,00	CASTROL - AWS 32			
MPC25-1/ MPC25-1D/ MPC25-1D-3	11,00	CASTROL - AWS 32			
MPC40-1/ MPC40-1D/ MPC40-1D-3	11,00	CASTROL - AWS 32			
EP100 D G5	27,00	CASTROL - AWHM 46			
EP100 D F G5	30,00	CASTROL - AWHM 46			
<u>Presses, Other models</u>					
ABP20	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
ADP10	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
AP15	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
AP20	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
BP15	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
DP10-B2, DP6-B2	1,25	CASTROL - AWS 22	CASTROL - AWS 32		

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
<u>Jacking beams</u>					
JB20					
JB20-2					
JB20-3	0,50	CASTROL - AWS 22			
JB20-4					
JB20A-4					
JB20A-5	0,50	CASTROL - AWS 22		95 - 100mm - Safety stop i top positio	8 - 10 bar
JB26-3	0,50	CASTROL - AWS 22			
JB26-4					
JB26A-5					
JB26A-5C	0,50	CASTROL - AWS 22		95 - 100mm - Safety stop i top positio	8 - 10 bar
JB28-3					
JB28-4					
JB50A-1					
RLB20 (G1)					
RLB20A (G1)					
RLB22 (G1)					
RLB22A (G1)					
RLB26 (G1)					
RLB26A (G1)					
RLB28 (G1)					
RLB28A (G1)					
RLB30 (G1)					
RLB30A (G1)					
<u>Transmission jacks</u>					
TH 450 LH	0,2 ??	CASTROL - AWS 22		Up to the edge of the refilling hole	
650-1	2,00	CASTROL - AWS 22		Up to the edge of the refilling hole	

Type	Liter	Type of oil	Alternative	Correct oil level	Air connection
TJ-T 750 TJ 1000 (G1) TJ-T 1300 (G2) TJ-T 2000 (G1)	0,95 2,80	CASTROL - AWS 32 CASTROL - AWS 32 CASTROL - AWS 32		Up to the edge of the refilling hole Up to the edge of the refilling hole Up to the edge of the refilling hole	
<u>Wheel Dollies</u> WD 1500 WD 60	0,80	CASTROL - AWS 22		10 mm under the refilling hole Up to the edge of the refilling hole	
<u>Other models</u> CPT 22 CPT 25 PT 25-C Updated 240429	0,75 0,75 0,75				